



# Process Quick Start Guide

## Bobcat™ welder/generators

 <b>WARNING</b>	
	<b>READ INSTRUCTIONS.</b> <ul style="list-style-type: none"><li>• Read and follow all labels and the Owner's Manual carefully before installing, operating, or servicing unit. Read the safety information at the beginning of the manual and in each section.</li></ul>

- 1. Registration** – Be sure to register your product at [www.Millerwelds.com/support/product-registration](http://www.Millerwelds.com/support/product-registration).
- 2. Operator's Manual** – Take out the operator's manual from the bag stored inside the service door. Refer to your operator's manual for specific installation instructions.
- 3. Remote Start/Stop Fob for Bobcat™ 225 and 260** – Remove Fob box from the operator's manual bag and set aside. The fob is already paired with your new machine and ready for use.
- 4. Exhaust** – The exhaust pipe and mounting bracket with hardware are packaged with the owner's manual. Install these components using a 1/2" combination wrench.
- 5. Battery** – The welder is shipped without the negative battery cable attached. Secure the negative battery cable to the negative battery terminal through the side door using a 1/2" combination wrench.
- 6. Oil** – Check the oil level. The unit is shipped with oil so the addition of oil is not necessary on new welders/generators.
- 7. Fuel** – Add fresh fuel to the welder and be sure to not overfill. See owner's manual for best fueling practices.
- 8. Air Compressor Oil** (Air Pak model only) – Check the air compressor oil gauge as described in the owner's manual. This unit is shipped with air compressor oil so the addition of oil is not necessary on new welders. See owner's manual for more details on the air compressor system.
- 9. Installation Location** – Verify 18" of clearance on each side and the top of the unit to ensure proper airflow for cooling.
  - Mount welder – Secure the welder to a rigid frame by fastening bolts through the four mounting holes on the base of the unit.
  - Electric Shock Protection – Ground the welder to the truck or trailer if applicable (ground cable not supplied). Detailed instruction available in the owner's manual.
- 10. Attach welding cables/connectors to the output terminals** – Be sure that the weld cables/connectors makes direct contact with the copper bar on the output

# Process Quick Start Guide

## Bobcat™ welder/generators

### Stick Welding

#### ▶ Getting Started



#### Ground Clamp (10 ft.) – 195458

Up to 400A, comes with stud/Tweco adapter.



#### Electrode Holder (10 ft.) – 195457

Up to 400A, comes with stud/Tweco adapter.

#### ▶ Do you need additional cable length?



#### Weld Cable Extension – 195456

2/0 Tweco, 50 ft.

#### Weld Cable Extension – 195455

2/0 Tweco, 100 ft.

#### ▶ Dinse Adapters for Cables



#### Dinse (male)/Tweco (female) adapter 042465



#### Tweco (male)/Dinse (female) adapter 210061

### MIG/FCAW-G Welding

#### ▶ Do you have a flowmeter/regulator?



#### Argon/CO2 Flowmeter Regulator

#### 22-80-580-6

CGA-580 inlet connection, 80 psi, 6 ft. air hose, gauge

#### ▶ Will wire welding be done with a spool gun?



#### WC-115 Control

#### 137546011

Enables spool gun functionality for machines without a remote receptacle. (Not required for the Bobcat™ 200 Air Pak™)



#### Spoolmatic 30A Spool Gun

#### 130831

200A aluminum spool gun, 30 ft. Requires WC-115 control to enable spool gun functionality (137546011).

#### ▶ Will you be using a SuitCase® feeder?\*

If so, what diameter wire spools will you use and what type of MIG gun would be best?

#### 8 inch wire spool diameter



#### ArcReach® SuitCase® 8

#### 951726

Includes BTB Q-Gun – 300A gun using premium Centerfire consumables with threadless contact tips.

#### 951727

Includes S-Gun™ – 250A gun using Quick Tip consumables with threaded taper lock contact tips.

#### 12 inch wire spool diameter



#### ArcReach® SuitCase® 12

#### 951729

Includes BTB Q-Gun – 300A gun using premium Centerfire consumables with threadless contact tips.

#### 951730

Includes S-Gun™ – 250A gun using Quick Tip consumables with threaded taper lock contact tips.

\*Bobcat™ welder/generators are not equipped with ArcReach® technology, so ArcReach feeders will run as standard voltage-sensing feeders when paired with these machines.

# Process Quick Start Guide

## Bobcat™ welder/generators

### FCAW-S Welding

#### ► What size wire spool does your SuitCase® feeder need to run?\*

8 inch maximum wire spool diameter



**ArcReach® SuitCase® 8**  
**951728**

With DuraFlux gun for the FCAW-S process.

12 inch maximum wire spool diameter



**ArcReach® SuitCase® 12**  
**951731**

With Dura Flux gun for the FCAW-S process.

\*Bobcat™ welder/generators are not equipped with ArcReach® technology, so ArcReach feeders will run as standard voltage-sensing feeders when paired with these machines.

### TIG Welding

#### ► Do you have a flowmeter/regulator?



**CO2, Argon, and Helium, 6 ft. air hose, gauge**  
**22-30-580-6**

CGA-580 inlet connection, 30 psi

#### ► Do you need a TIG consumable kit?



**Torch Consumable Kit**  
**AK3C**



**Gas Lens Kit**  
**AK3GL**

For 150A, 200A and 250A torches. Sizes 6, 7 and 8.

#### ► What amperage torch will you need?



**Weldcraft A-150A Valve Torch**

Rubber, 25 ft.

Standard - **WP-17FV-25-R**

Flex - **WP-17FV-25-R**

Pair with connector - **105Z57**



**Weldcraft A-250A Valve Torch**

Rubber, 25 ft.

Standard - **301526025**

(two piece only - no adapter)



**One Piece TIG**

**Connector**

**105Z57**

Pair adapter with 150A torch



**One Piece TIG**

**Connector**

**45V62**

Pair adapter with 200A torch

# Process Quick Start Guide

## Bobcat™ welder/generators

### Battery Charge/Jump Start (for Bobcat™ 200 Air Pak™)



**Battery Charge/Jump Start Cables**  
**300422**

25 ft. cables with plug

### Air Compressor (for Bobcat™ 200 Air Pak™)



**Air Dryer Kit**  
**301488**

Cools and removes moisture from the air supply

## Plasma Cutting

▶ **The cutting capabilities will be based on the output of the machine. See Spectrum literature for power requirements.**



**Spectrum 375**  
**907529**

Rated to cut 3/8" material



**Spectrum 625**  
**907579**

Rated to cut 5/8" material



**Spectrum 875**  
**907583**

Rated to cut 7/8" material



**Full KVA Adapter Cord**  
**300517**

NEMA 14-50 to NEMA 6-50R  
for easy pairing with equipment  
such as Spectrum series plasma  
cutters.