


# Rolling Inductor Software Kit Components

The following components make up the Rolling Inductor software kit:

- 1 programming dongle and cable
- 1 USB mini 5-pin cable
- 2 programming pods
- 1 connection pcb # 268275
- 1 connection cable # 253431
- 1 power adapter (115V – 5V)
- 1 battery

Electronic Documents from Extranet

- 1 Installation Instructions (266593)
- Current version software  
(.a90 & .fob files)



# Replacement Component Specifications


- 115V power adapter (non-CE)
  - [www.Digikey.com](http://www.Digikey.com) WSU050-3000
    - Positive center, Barrel Plug, 2.1mm I.D. x 5.5mm O.D. x 11.0mm
- CE version, it is available from [rswww.com](http://rswww.com) part number 7316002
  - Non European countries use <http://www.rs-components.com/index.html> for a local source.
- These programming pods work great for updating software in many Miller power sources. Additional units can be purchased from Kanda:
  - Adapter + 1 Pod - <http://www.kanda.com/products/Kanda/KF0010U.html>
  - 1 Pod - <http://www.kanda.com/products/Kanda/KF0020U.html>
  - Adapter + 6 Pods Kit - <http://www.kanda.com/products/Kanda/KF0040U.html>
- One connection pcb and cable assembly is required for each pair of pods to connect the pod to the power source PCB.
  - 268275 CIRCUIT CARD ASSY,KANDA PROGRAM ADAPTER
  - 253431 PLUGS,W/LEADS

# Copy Files to Computer





- Create a folder on your computer to copy the .a90 and .fob files.
  - If a folder already exists, delete any previous revision files.

- Copy the files:

- from the email



- to the folder  
on your computer.

Name ^	Type
 ProHeat_OperatorInterface.fob	FOB File
 ProHeat_PowerSource.fob	FOB File
 ProHeatOperatorInterface_Rev1.26.a90	A90 File
 ProHeatPowerSourceMicro_Rev1.23.a90	A90 File

# Kanda Programming Software


- Download the current version of **AVR Keyfob-USB** software from Kanda.  
<http://www.kanda.com/dload/soft/110448-2.10-avrkfusb-v2.1.0.zip>

- Save the .zip file to your computer
- Double click the .zip file to open WinZip




# Install the avrkfusb Software.

- Double click the avrkfusb-v2.1.0.exe




- Click Yes to begin the install




# Security Warning

- You may see a Security Warning
- Click Run




# Setup

- Close open programs
- Then click Next



# License Agreement


- Review the License Agreement
- Indicate if you accept the agreement
- Then click Next






# Setup

- Click Next




# Setup

- Click Next




# Setup

- Click Next




# Setup

- Click Install




# FTDI CDM drivers

- Click Extract




# Device Driver Installation Wizard

- Click Next




# Device Driver Installation Wizard

- Click Finish



# Setup


- Click Next






# Setup

- Click Next



# Setup

- Click Finish



- Close the README file