# PerformArc PA1500SW

Automation Systems

# **Robotic Welding Cell**

# **Ouick Specs**

#### **Industrial Applications**

Contract manufacturing Automotive components Recreational vehicles Farm/construction machinery **Implements** Office furniture Food equipment

#### **Product Type**

Servo-driven indexing turntable Station A: for load/unload Station B: robot /weld envelope Single- or dual-robot configuration

#### **Processes**

MIG (GMAW): Auto-Continuum™ 500 MIG (GMAW): TAWERS 350/450/Active Wire TIG (GTAW): TAWERS WG3 300A DC

#### **Machine Dimensions**

Height: 90 in. (2,286 mm) Width: 120 in. (3,050 mm) Depth: 204 in. (5,182 mm)

#### **Payload Capacity**

1,500 lb. (680 kg) per station

#### **Input Power**

Standard: 480 V

Optional: 208, 230, 240, 575 V

PerformArc PA1500SW has features similar to our smaller turntable units. but provides our largest footprint and payload capacity. Workpiece shuttles into an enclosed robot envelope on our largest servo-driven index table. Single- and dual-robot configurations provide higher throughput capacity.









Easy integration of various weld processes and capabilities



Welding throughput versus manual welding



Visit HobartBrothers.com for your filler metal solutions.



Major components except torches, consumables, and power supplies. Refer to specific component warranty for more information.





#### **Miller Welding Automation**

An ITW Welding Company 281 E. Lies Rd. Carol Stream, IL 60188 USA

#### **Equipment Sales**

Phone: 630-653-6819 Email: MWASales@millerwelds.com









# **PerformArc™ PA1500SW**


**PA1500SW** is our highest payload, largest work envelope in a turntable arrangement. It operates in the same manner as our PA750, but the turntable is much larger. The larger footprint accommodates dual robots if needed, for higher throughput or welding of multiple parts.

**Operator protection** is accomplished with sliding doors and an arc shield that indexes with the turntable. Light curtains prevent operator from entering an active workstation.

**Ships fully assembled and easy to install.** Position with a forklift, secure to floor and connect utilities.

**Easy to relocate.** Simply disconnect utilities and floor anchors, move with a forklift, and re-anchor and reconnect utilities.

Full complement of capabilities. GMAW, GTAW, OptiDrive™ push-pull torch, active wire pull torch, and advanced arc modes (Accu-Pulse®, Versa-Pulse™, SP MAG, RMD®) to grow with your needs.





# **PerformArc** PA1500SW Machine Specifications

| Input Power  | Standard Arc Welding Configuration  | Optional Configurations Available  |
|--|---|--|
| Standard: 3-phase, 480 V, 30 A<br>Optional: 208 V, 230 V, 240 V, 575 V | Arc welder: Miller Auto-Continuum™ 500<br>Wire drive: Miller Auto-Continuum™<br>Single robot: TM1400 or TM1600<br>Dual robot: TM1400 or TM1600<br>Welding torch: Tregaskiss® air cooled | Active wire GMAW: Panasonic TAWERS and torch Pull torch solutions: Miller OptiDrive™ and Dinse torch GTAW: TAWERS WG3 300A DC High deposition: Hercules™ |

| Approximate Dimensions  |   | Approximate Shipping Weight   | Payload Capacity               |
|---|---|---|--------------------------------|
| Height: 90 in. (2,286 mm)<br>Width: 120 in. (3,050 mm)<br>Depth: 204 in. (5,182 mm) | Max. tool height: 40 in. (1,016 mm) Load height: 33 in. (838 mm) Cell front opening: 103 in. (2,616 mm) Rotation diameter: 108 in. (2,743 mm) | Single robot: 7,000 lb. (3,175 kg) Dual robot: 8,100 lb. (3.674 kg) | 1,500 lb. (680 kg) per station |

Note: Refer to sales drawings for more specific specifications.









### **Resources When You Need It**

#### **Pre-Sales Application Support**

Contact Miller Welding Automation prior to sale to discuss possibilities to support and prove out your unique welding challenges. Our lab can complete trials and make recommendations that will help reduce risk in your purchasing decision. We'll review your access requirements and hook-up needs — air, gas or electric — prior to installation. Our goal is to have your PerformArc™ welding cell up and running the day it arrives your facility.

#### **Training**

We offer virtual training as well as in-person training at our different facilities to fit your needs. Training programs are offered for PerformArc operation and for our offline programming software — Desk Top Programming and Simulation (DTPS). Contact your Miller Welding Automation representative for more information.

# Post-Sale Service and Preventative Maintenance

Contact Miller Welding Automation for service and preventative maintenance recommendations and programs, as well as troubleshooting of any operation issues.

### **Job Plate**

| Miller Welding Automation 281 East Lies Road Carol Stream, IL 60188 USA Phone: 630-653-6819 www.MillerWelds.com / MWAService@itwwelds.com Assembled in USA |                              |  |  |
|--|------------------------------|--|--|
| Model Type   | PAXXXXXX                     |  |  |
| Serial Number  | JXXX                         |  |  |
| Primary Input Voltage  | 480V XYZ                     |  |  |
| Number of Phases   | 3                            |  |  |
| Frequency  | XYZ Hertz                    |  |  |
| Rated Current  | XYZ Amps                     |  |  |
| Maximum Interrupt Current  | XYZ,000 Amps                 |  |  |
| Electrical Drawing Index   | PAXYZS-SXXX ELEC 0X-2X-X.dwg |  |  |
| Date of Manufacture  | October 2055                 |  |  |
| Mechanical Revision  | J40XX                        |  |  |
| System Weld Torch Specification<br>Manufacture - Tregaskiss<br>For Parts Information Contact Miller Welding Automation                                     |                              |  |  |
| CAX Torch, X ft., Pana, Brake  | RAX12ABAXYZ                  |  |  |
| Mounting Arm   | XX-306-X59-X                 |  |  |
| Insulation Disc, TM  | 5XDX-9ZZ                     |  |  |
| Control Cable, Panasonic   | ZZ-7X5-0X                    |  |  |
| Contact Tips, .XXX, Acculock   | B-Y010CH                     |  |  |
| Contact Tips, .YYY, Acculock<br>Nozzle Reamer/ Wire Cutter   | C-Z010CH<br>ZZ9A45XXXXWL     |  |  |
| NOZZIE REAMER/ WIRE Cutter   | ZZSM40XXXXVL                 |  |  |

Need help or have questions about your PerformArc system? Our 24/7 service line can assist you when you need it most. Our service team can help you with operation questions, or to arrange preventative maintenance. The job plate on the back of your system will provide you with quick access to important information about your system like part numbers for your consumables.

# **Contact Us**

**Miller Welding Automation** is your single point of contact for configuring and ordering your PerformArc system.

**Continued technical support** can be counted on from Miller Welding Automation in Carol Stream, Illinois. Please call our hotline number: (630) 653-6819.

**Spare parts and wear items** are provided in your initial purchase of PerformArc. Spare parts can be ordered from Miller Welding Automation.

Distributed by:

